

ASSEMBLY GUIDE

DR19 Single Drawer



Contents

ASSEN	MBLY INSTRUCTIONS	3
	PREPARATION	
	ASSEMBLY FASTENER KIT	
	INSTALLATION FASTENER KIT	
	DRAWER ASSEMBLY	


Required Items

- ☐ Rivet Gun or Rivet Tool
- ☐ Utility Knife

ASSEMBLY INSTRUCTIONS

1 PREPARATION

Review the BOM and ensure that all of the parts are present.



BILL OF MATERIALS

Item Number	Part Number	Description	Quantity
1	X-DR19-01	Drawer	1
2	X-DR19-02	Drawer Mount Bracket	2
3	X-DR19-03	Divider	2
4	X-DR19-04	Brace	2
5	X-DR19-06	Drawer Front Plate	1
6	ADS 7650-16 LH	16" Lock-In/Lock-Out Slide, 500/300lb	3
7	ADS 7650-16 RH	16" Lock-In/Lock-Out Slide, 500/300lb	4
8	DRP-SG21-24000	Drawer Release Handle, 24" Wide	1
9	66-50606	Standard Rubber Matting, 1/8"	1

2 ASSEMBLY FASTENER KIT

Quantity	Description	Image	Purpose	
21	Aluminum Blind Rivet 3/16" x 1/2" LG	×	- Assembling Drawer	
16	Steel Blind Rivet 3/16" x 1/2" LG	*		

3 INSTALLATION FASTENER KIT

Quantity	Description	Image	Purpose
10	Hex Washer Head Screw #14 x 3/4"	0	Installing the drawer

4 DRAWER ASSEMBLY

- 1. Ensure your work surface is clean and smooth to minimize surface scratches. Working on cardboard or foam sheet is recommended.
- 2. Before assembling, unmask the protective film from all surfaces of each part.
- 3. Rivet the corners of the drawer.
- 4. Rivet the Drawer Front Plate to the front of the drawer.
- 5. Rivet the Drawer Slides to the drawer as shown using Steel Rivets. Make sure that they pivot
- 6. Rivet the Drawer Slides to the Drawer Mounts as shown using Steel Rivets. Make sure that the mount holes are facing up.
- 7. Rivet the Drawer Braces to the Drawer Mounts as shown.
- 8. Fasten the Drawer Release Handle to the Drawer Slides.
- 9. Place the rubber mat in the drawer. (19-7/8" x 15-3/4")
- 10. Slide the dividers into place or place them in the drawer if being shipped.

