




# INSTALLATION GUIDE

CL10

Locking Cab Box Organizer





**ATTENTION**

## **PRIOR TO INSTALLATION:**

**PLEASE CAREFULLY READ AND ADHERE TO ALL WARNINGS AND INSTALLATION GUIDELINES BEFORE USING THIS PRODUCT. FAILURE TO DO SO MAY RESULT IN PROPERTY DAMAGE, SEVERE BODILY INJURY, AND/OR LOSS OF LIFE. THE MANUFACTURER DISCLAIMS ANY RESPONSIBILITY FOR PROPERTY DAMAGE, PERSONAL INJURY, OR FATALITIES THAT MAY OCCUR WHILE UTILIZING PACKD PRODUCTS.**

- Neglecting to utilize the provided fasteners, brackets, and following proper installation guidelines may heighten the risk of severe personal injury and/or fatality.
- In instances where drilling is necessary for installation, improper drilling may lead to vehicle damage, electric shock, fire, or fatality.
- If drilling is necessary, ensure that it is restricted to areas authorized by the vehicle's Original Equipment Manufacturer's Body Builders Layout Book (or equivalent document).
- Prior to drilling, verify that critical vehicle components such as the gas tank, wiring harness, or hoses will not be impacted. Consult the vehicle OEM documentation as needed and use a drill collar during drilling to minimize the risk of vehicle damage.
- Before installation, inspect the vehicle to guarantee that the installation will not obstruct critical components such as electrical wiring, fuel tanks, fuel cells, locks, latches, etc.
- The installer or upfitter is responsible for ensuring that anchorages are securely installed on appropriate wall and floor structures.
- Avoid installing systems into weak or unsound materials such as plastics, woods, thin-walled metals, etc., without proper reinforcement.
- Do not install this product in a manner that could interfere with airbag deployment.
- Incorrect installation may lead to water leaks, electric shock, or fire.
- Secure all items in the cargo area properly, and close partition doors while the vehicle is in motion.
- Any modification or unintended use of this product could create a hazardous condition and void the warranty.
- Opt for professional installation conducted by certified technicians well-versed in vehicle upfitting procedures. Entrusting the installation to amateurs could jeopardize both the effectiveness and safety of the product.
- Adhere to local, state, and federal regulations governing vehicle modifications. Failure to comply with these regulations may result in serious legal consequences.

# Contents

ASSEMBLY INSTRUCTIONS (TRANSIT) .....	4
1. PREPARATION .....	4
2. INSTALL FASTENER KIT (TRANSIT) .....	4
INSTALLATION INSTRUCTIONS (TRANSIT) .....	5
ASSEMBLY INSTRUCTIONS (SPRINTER) .....	6
1. PREPARATION .....	6
2. INSTALL FASTENER KIT (SPRINTER) .....	6
INSTALLATION INSTRUCTIONS (SPRINTER) .....	7

## Required Items (Transit)

- ☐ 1/4" Drill Bit
- ☐ 7/16" Nut Driver Bit
- ☐ Marker
- ☐ Cordless Drill
- ☐ Cordless Impact Driver
- ☐ Level


## Required Items (Sprinter)

- ☐ 1/4" Drill Bit
- ☐ 7/16" Nut Driver Bit
- ☐ Marker
- ☐ Cordless Drill
- ☐ Cordless Impact Driver
- ☐ Level

# ASSEMBLY INSTRUCTIONS (TRANSIT)

## 1. PREPARATION (TRANSIT)





Unpack components and compare to the Bill of Materials. Ensure that all of the parts are present.



## BILL OF MATERIALS





Part Number	Description	Quantity
CL10	Locking Aluminum Cab Box Organizer	1
5040-TB-A	Cab Box Mounting Bracket, Rear	1
5040-TB-B	Cab Box Mounting Bracket, Front	1
	Install Fastener Kit	1

## 2. INSTALL FASTENER KIT (TRANSIT)

Quantity	Description	Image	Purpose
4	Hex Bolt 1/4-20 x 3/4		Fastening mounting brackets to Cab Box
4	Flat Washer 1/4		
4	Serrated Nut 1/4-20		
8	Hex Washer Head Screw #14 x 3/4		Fastening mounting brackets to the vehicle

# INSTALLATION INSTRUCTIONS (TRANSIT)


1. Locate the Front mounting Bracket onto the front of the seat frames as shown below. Level the mounting bracket from left to right and fasten it in place.
2. Put the Cab Box in place and bolt the front of the box to the front mounting bracket making sure that the nuts are on the outside of the box.
3. Level the Box out from front to back and use the rear mounting bracket to mark holes in the box and the passenger seat frame.
4. Drill out the marked holes in the cab box using a 1/4" drill bit.
5. Fasten the mounting bracket to the seat frame using the provided Cap Screws in the location that was marked.
6. Bolt the Rear of the Cab Box to the Rear Mounting Bracket with the nuts on the outside of the box.



# ASSEMBLY INSTRUCTIONS (SPRINTER)

## 1. PREPARATION (SPRINTER)









Unpack components and compare to the Bill of Materials. Ensure that all of the parts are present.



## BILL OF MATERIALS


Part Number	Description	Quantity
CL10	Locking Aluminum Cab Box Organizer	1
MB01	Cab Box Mounting Bracket, Rear	1
	Install Fastener Kit	1

## 2. INSTALL FASTENER KIT (SPRINTER)

Quantity	Description	Image
4	Hex Bolt 5/16-18 x 3/4	
2	Hex Bolt 5/16-18 x 1-3/4	
6	Flat Washer 5/16	
4	1/4" Nylon Spacer	
4	Serrated Nut 5/16-18	
2	Plus Nut 5/16-18	
2	Hex Washer Head Screw #14 x 3/4	
1	5/16" Plus Nut Tool	

# INSTALLATION INSTRUCTIONS (SPRINTER)


1. Mark the rear of the box in the locations shown below and drill out using a 3/8" drill bit.
2. Place the cab so that the top holes line up with the protruded face in the factory partition. Use the holes drilled in the previous step to make marks on the partition. Drill top holes using a 1/2" drill bit and the bottom holes using a 3/8" drill bit.
3. Use the provided tool to install plus nuts into the 1/2" holes.
4. Fasten the rear of the Cab Box to the partition.
5. Making sure that the box is level, use the provided mounting bracket to mark holes on the front of the box and the base of the passenger seat. Drill 3/8" holes in the front of the cab box.
6. Fasten the mounting bracket to the passenger seat frame on the marks made in the previous step.
7. Bolt the front of the box to the mounting bracket ensuring the box is still level.




**(A) Using Plus Nut Gun:** (If available- otherwise see B below)

- Place 2 drops of air tool oil into the air fitting regularly.
- Ensure that there is anti-seize on the Plus Nut Gun threads at all times.
- Thread a Plus Nut onto the threads of the gun, then place bolt and Plus Nut through pre-drilled hole.
- Pull trigger of Plus Nut Gun to compress Plus Nut into the material until the noise changes on the gun.
- Reverse direction on gun to unscrew Bolt from the Plus Nut.

**FORWARD**



**REVERSE**



**(B) Using Plus Nut Tool:**

**STEP 1**


Assemble the Plus Nut Tool as shown.

**Tools:**

9/16" Wrench

**Hardware:**

Plus Nut Tool



**STEP 2**

Fasten Plus Nut to vehicle:

- Insert Plus Nut into hole.
- Hold Nut with wrench.
- Tighten bolt until Plus Nut clamps the vehicle body metal tightly.

**Tools:**

Cordless Impact Driver

1/2" Nut Driver Bit

9/16" Wrench



**Hardware:**

4 x 5/16" Plus Nuts

Plus Nut Tool





You have successfully installed your Locking Aluminum Cab Box Organizer! If you have any questions or concerns, please contact us at (888)-214-0333.





You have successfully installed your Locking Aluminum Cab Box Organizer! If you have any questions or concerns, please contact us at (888)-214-0333.